

Help Line

Australia

Canada

México

United States

+ 1-800-33-11-77

+ 1-800-665-4339

+ 1-800-234-1185

+ 1-800-955-0959

Fellowes

Australia

Benelux

Canada

Deutschland

France

Italia

Japan

Korea

Malaysia

Polska

España

Singapore

United Kingdom

United States

+ 61-3-8336-9700

+ 31-(0)-76-523-2090

+ 1-905-475-6320

+ 49-(0)-5131-49770

+ 33-(0)-1-30-06-86-80

+ 39-071-730041

+ 81-(0)-3-5496-2401

+ 82-2-3462-2884

+ 60-(0)-35122-1231

+ 48-(0)-22-771-47-40


+ 34-91-748-05-01

+ 65-6221-3811

+ 44-(0)-1302-836836

+ 1-630-893-1600

www.fellowes.com




DS-2

Please read these instructions before use.

ENGLISH


Model DS-2



Breakthrough Safety Technology! SafeSense™ stops shredding when hands are too close to the opening.

SET-UP

— To Test SafeSense™ Technology



CAPABILITIES

Will shred: Paper, small paper clips, credit cards and staples

Will not shred: Continuous forms, adhesive labels, transparencies, newspaper, cardboard, large paper clips, laminates or plastic other than noted above

Paper shred size: Confetti-Cut 5/32" x 2" (3.9 x 50mm)

Maximum: Sheets per pass (Confetti-Cut) 8*
Cards per pass 1
Passes per day 10-20
Paper width 9" / 229mm
Continuous operation 2-4 minutes
*20 lb., 8.5" x 11" paper at 120v, 60 Hz, 3.5 Amps; heavier paper, humidity or other than rated voltage may reduce capacity.

IMPORTANT SAFETY INSTRUCTIONS — Read Before Using!


WARNING

- Keep away from children and pets. Keep hands away from paper entry. Always unplug when not in use.
- Keep foreign objects – gloves, jewelry, clothing, hair, etc. – away from shredder openings. If object enters top opening, press and hold Reverse (R) to back out object.
- Never use aerosol, petroleum-based or other flammable products on or near shredder. Do not use canned air on shredder.
- Do not use if damaged or defective. Do not open shredder head. Do not place near or over heat or water source.
- 8 sheets per pass to avoid jams.

CAUTION


- Avoid touching exposed blades under Confetti-Cut shredder head.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.

OPERATION




TROUBLESHOOTING

Paper jam: Set to Off (O), remove shredder head and empty bin. Replace shredder head, and follow any or all of the below procedures.




ATTENTION: If the SafeSense™ light remains on, you must engage the **Override Switch** in order to perform steps above. Once the jam is cleared, reset the SafeSense™ feature. (See SafeSense™ instructions below.)



MAINTENANCE

Run regularly in reverse for one minute

- Oil when bin is full, or immediately, if:
 - Capacity decreases
 - Motor sounds different, or Shredder stops running



WARRANTY

LIMITED WARRANTY Fellowes, Inc. ("Fellowes") warrants the cutting blades of the machine to be free from defects in material and workmanship for 5 years from the date of purchase by the original consumer. Fellowes warrants all other parts of the machine to be free of defects in material and workmanship for 1 year from the date of purchase by the original consumer. If any part is found to be defective during the warranty period, your sole and exclusive remedy will be repair or replacement, at Fellowes' option and expense, of the defective part. This warranty does not apply in cases of abuse, mishandling, or unauthorized repair. ANY IMPLIED

WARRANTY, INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS HEREBY LIMITED IN DURATION TO THE APPROPRIATE WARRANTY PERIOD SET FORTH ABOVE. In no event shall Fellowes be liable for any consequential or incidental damages attributable to this product. This warranty gives you specific legal rights. The duration, terms, and conditions of this warranty are valid worldwide, except where different limitations, restrictions, or conditions may be required by local law. For more details or to obtain service under this warranty, please contact us or your dealer.