



Clarity™ Monitor Riser

(9731001)

Support moniteur Clarity™

Soporte para monitor transparente Clarity™

Clarity™ Monitor Ständer

Clarity™ Supporto monitor





Clarity™ monitorstandaard

Clarity™ Monitorställ

Clarity™ podstawa pod monitor

Подставка для монитора Clarity™

Soporte para monitor transparente Clarity™



Caution: Monitor base must fit within top surface area (228mm x 228mm).

Attention : la base du moniteur doit s'adapter à la surface supérieure (228 mm x 228 mm).

Precaución: la base del monitor debe encajar en la superficie superior (228 mm x 228 mm).

Achtung: Der Monitorsockel muss in den oberen Oberflächenbereich (228 mm x 228 mm) passen.

Avvertenza: la base del monitor non deve essere più grande del piano di supporto (228 mm x 228 mm).

Let op: de monitorvoet moet binnen het bovenste oppervlak passen (228 mm x 228 mm).

Varning: Monitorbasen måste få plats helt på ytan (228 mm x 228 mm).

Uwaga: podstawa monitora nie może wystawać poza górną powierzchnię podstawy (228 mm x 228 mm).

Внимание! Основание монитора должно соответствовать по площади размеру поверхности (228 мм x 228 мм).

Advertència: A base do monitor terá de caber na área de superfície superior (228 mm x 228 mm).